
ARTICLE.

VERSION 1.1

Assembly Instructions



LUBEK

Sectional


ARTICLE. LUBEK Sectional Page 2 of 6

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.




A RIGHT SIDE SECTION 1 B LEFT SIDE CORNER SECTION 1 C RIGHT SECTION LARGE BACKREST (45") 1
B LEFT SIDE CORNER SECTION 1
RIGHT SECTION LARGE BACKREST (45") 1
LEFT SECTION LARGE BACKREST (59") 1
LEFT CORNER SMALL BACKREST 1
LEFT SEAT CUSHION (65")
G RIGHT SEAT CUSHION (66")
H CORNER SEAT CUSHION 1
LEFT LONG BACK CUSHION (63")
RIGHT LONG BACK CUSHION (75")
K SMALL BACK CUSHION 5


Hardware may loosen over time, check the bolts regularly and tighten if necessary.


PARTS INVENTORY CONT.				
ID	DESCRIPTION		QTY	
	M6 WASHER		8	
M	M6 LOCK WASHER		8	
Z	M6 × 20MM BOLT	(I))))))))))))))))))))))))))))))))))))	8	
0	ALLEN KEY		2	
Ф	CONNECTOR BRACKET		2	
Q	M8 WASHER		4	
R	M8 LOCK WASHER		4	
8	M8 × 20MM BOLT		4	






Secure bolts to large backrest (C) on the underside of right side section (A).







Secure bolts to backrests (D/E) on the underside of left corner section (B).









ARTICLE. LUBEK Sectional Page 6 of 6



