


ARTICLE.

VERSION 1.2

Assembly Instructions



MADERA

Extendable Dining Table

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.





TIME













OF PEOPLE




DIFFICULTY


PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	CENTER BAR	1
B	CENTER BAR ATTACHMENT 	1
C	CENTER BAR BRACKET 	1
D	LEGS	2
E	EXTENSION LEAF	2

PARTS INVENTORY CONT.		
ID	DESCRIPTION	QTY
F	ALLEN KEY 	2
G	M8 × 20MM BOLT 	1
H	M8 LOCK WASHER 	17
I	M8 WASHER 	17
J	M8 × 30MM BOLT 	16
K	M6 × 20MM BOLT 	2
L	M6 LOCK WASHER 	2
M	M6 WASHER 	2
N	NUT 	2
O	SOCKET WRENCH 	1


1A




1B




2




3A




3B



4




5



! Secure nuts (N) on both ends of center bar after legs are bolted to table top.

6




! Dowels on extension leaves (E) fit into holes at the end of each extension arm.

EXTENSION LEAF ADJUSTMENT INSTRUCTIONS



If your extension leaves don't line up with the main table surface properly, the bolts on the arms underneath the table top can be adjusted. Loosen the bolts to move the arms further out from the table and tighten to move the arms further in.



To adjust the gap between ext leaf and main table top.

If the extension leaves & main table top are uneven, adjust the bolts to make the extension leaves and main table top flush.



If bolts are too loose: arms can extend too far and come out of the table completely.
If bolts are too tight: arms will not extend far enough to align with dowels on leaf.