


ARTICLE.

VERSION 1.0

Assembly Instructions



MEKLEN

Lounge Chair

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


If you’re having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.




TIME







OF PEOPLE




DIFFICULTY



 Note: Locknuts should be taken from the Turntable Basic.

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	CHAIR BODY 	1
B	TURNTABLE BASIC 	1
C	LOCKNUT 	4
D	OPEN END WRENCH 	1


1




Please lay the chair body (A) on soft, clean surface with suitable height before assemble loose the locknuts (C) from the turntable basic with the open end wrench (D).





2




Place the turntable basic (B) in the right assembly position at the bottom of chair body (A).



3



Attach the chair body (A) and turntable base (B) with locknut (C) and tighten.



4

