


ARTICLE.

VERSION 1.1

Assembly Instructions



CHANTEL


Dining Chair

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


If you’re having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.








TIME / CHAIR



OF PEOPLE



DIFFICULTY

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	FRONT LEGS	2
B	BACK LEGS	2
C	ALLEN KEY 	1
D	M6 × 70MM BOLT 	8
E	M6 LOCK WASHER 	8
F	M6 WASHER 	8
G	FELT PAD 	4

1

A

B

! Back legs (B) are more angled.

B

A

B

A

C

D

E

F

85%

× 8

2

G

× 4

100%

! Fully tighten all bolts after turning upright.