
ARTICLE.

Assembly Instructions



DAKO


Extendable Dining Table

ASSEMBLY INSTRUCTIONS


Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.


When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.





PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	TABLE TOP	1
B	FEET	2
C	EXTENDABLE LEFT TABLE TOP	1
D	EXTENDABLE RIGHT TABLE TOP	1
•	WOODEN DOWEL	14
•	M8 × 25MM BOLT	8
G	M8 × 70MM BOLT	8
(1)	LOCK WASHER	16
0	WASHER	16
0	ALLEN KEY	1







(3






(4)













Unlock to adjust tabletop.


























! Lock to fix table top location.