
# ARTICLE.

## **Assembly Instructions**



# **NERA**


6 Drawer Low Double Dresser

#### ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.


When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.





PARTS INVENTORY				
ID	DESCRIPTION		QTY	
A	CENTER LEG		1	
B	SIDE LEG FRAME		2	
G	M6 × 15MM BOLT		16	
D	ALLEN KEY		1	






## SOFT CLOSING DRAWERS - NERA


### **ADJUSTMENT INSTRUCTIONS**

FIX A CROOKED DRAWER




If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.










### ARTICLE.



1010 Raymur Ave. Vancouver, BC V6A 3T2



## ANTI-TIP RESTRAINT INSTALLATION




### WARNING!

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- · ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lower drawers.







REQUIRED TOOL 8MM / 5/16" DRILL BIT

REQUIRED TOOL

PARTS INVENTORY			
ID	DESCRIPTION	QTY	
A	ANGLE PLATE	2	
B	Ø 4 × 45MM SCREW	2	
C	Ø 8 × 40MM PLUG	2	
D	M5 × 18MM WASHER	2	
•	Ø 3,5 × 13MM SCREW ∰im>	4	



