


# ARTICLE.

VERSION 1.1

## Assembly Instructions




Rosa Dining Table

ASSEMBLY INSTRUCTIONS


Read these instructions carefully and keep for future reference. R efer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


If you’re having difficulty, our friendly Customer Care team is always here to help . Call us at 1.888.746.3455 during business hours, email [service@article.com](mailto:service@article.com) or chat live at [article.com](https://article.com) .






TIME



2 OF PEOPLE






DIFFICULTY

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	Table top 	1
B	Table leg 	4
C	Umbrella cap 	1




Hardware may loosen over time , check the bolts regularly and tighten if necessary .

HARDWARE INVENTORY		
ID	DESCRIPTION	QTY
D	Washer $\varnothing$ 25x2mm 	8
E	Hex nut M8 	8
F	Open Wrench #13 	1

1

- ❗ Place table top (A) upside down on a padded non-marry surface. Insert leg (B) so that the bolts go through predrillet holes at table top corner. Secure the washer (D) and hex nut (E) by using the open wrench (F).



Repeat the above steps for the other legs

Tip: User are advised to secure the hex nut by hand first, before using open wrench fully tighten it.

2

- Turn the table upright and adjust the levelers at the bottom of the legs (if needed) to balance the table.
- Put on the umbrella cap if you do not pair the table with an umbrella.

