

Assembly Instructions



ZEBU TALL


Floor Lamp

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

If you're having di culty, our friendly Customer Care team is always here to help. Call us at 1.888.746.3455 during business hours, email service@article.com or chat live at article.com.




OF PEOPLE


REQUIRED TOOL


PARTS INVENTORY			
ID	DESCRIPTION	QTY	
A	LAMP TOP SEGMENT WITH SOCKET	1	
B		1	
С		1	
D	BASE	1	
e	LAMP SHADE TOP	1	
Ø	LAMP SHADE BOTTOM	1	
G	DIFFUSER	1	
0	SOCKET RING (PRE-INSTALLED)	1	
0	BULB	1	
0	STEEL TUBE (PRE-INSTALLED)	1	

PARTS INVENTORY CONT.			
ID	DESCRIPTION	QTY	
K	SCREWS 8/32x8mm	4	
C	WASHER 32mm (PRE-INSTALLED)	2	
M	NUT Ø19x8mm (PRE-INSTALLED)	3	
R	WRENCH	1	
0	WASHER 38mm (PRE-INSTALLED)	2	
P	FELT PAD	1	



EXTRA PARTS





ZEBU ECRU Floor Lamp Page 5 of 7

