
ARTICLE.

VERSION 1.0

Assembly Instructions



COSGROVE

78" Media Unit


ARTICLE. Cosgrove 78" Media Unit Page 2 of 10

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.




PARTS INVENTORY					
ID	DESCRIPTION		QTY		
A	MEDIA UNIT		1		
B	LEGS		2		
C	SHELF		2		

PARTS INVENTORY CONT.					
ID	DESCRIPTION		QTY		
D	M6 WASHER		8		
•	M6 LOCK WASHER	0	8		
•	M6x60 BOLT		8		
G	ALLEN KEY		1		
•	SHELF PIN		8		







Place the shelf C inside the cabinet



Lift the shelf C upwards when attaching the shelf pin H at the choosen location





Lower the shelf C onto the shelf pin H






Repeat step 2 and 3










ANTI-TIP RESTRAINT INSTALLATION



WARNING!

Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lower drawers.








TIME # OF PEOPLE

DIFFICULTY






REQUIRED TOOL 8MM / 5/16" DRILL BIT

REQUIRED TOOL


PARTS INVENTORY					
ID	DESCRIPTION		QTY		
A	BRACKET		4		
B	M4 × 20MM SCREW	gama.	4		
G	M8 × 51MM PLUG		4		
D	M6 × 70MM SCREW	annal	4		
•	STRAP	Ö	2		

Hardware (C/D) to attach brackets to wall is designed for drywall. To attach this unit to another type of wall, consult with your local hardware store.






Attach pair of brackets to top corners of the back of the unit. Note there are no existing pilot holes on the product.



Mark on wall where second pair of brackets should be placed.







Drill holes in wall using 8mm / 5/16" drill bit.



Align brackets on unit with brackets on wall.








Pull strap down until it snap-locks.

ARTICLE. Cosgrove 78" Media Unit Page 9 of 10

DOOR ADJUSTMENT INSTRUCTIONS


During shipping, the doors of your cabinet may have shifted slightly. This can easily be corrected by tightening a few screws. Always start by adjusting the top hinge on the affected door.




REQUIRED TOOL




If the door is crooked, adjust hinge(s) up or down:







If the door needs adjustment side to side:





If the door needs adjustment forward or backward:

