


ARTICLE.

VERSION 1.0

Assembly Instructions




SAREK
Dining Bench

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email service@article.com or chat live at article.com.



TIME



2 PEOPLE




LEVEL

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	TABLE TOP	1
B	LEG FRAME	2

HARDWARE LIST			
ID	DESCRIPTION	QTY	
C	BOLT M6x15	10	
D	LOCK WASHER M6	10	
E	WASHER M6	10	
F	ALLEN KEY #4 x 100	1	


1

Align assembly holes on table top (A) with inserted nuts on the leg (B) first. Align the assembly hole insert nuts on leg (B)



2

Assemble them together using bolt (C), lock washer (D), washer (E) and tighten by Allen key (F).



3

Put the product up right.

