


ARTICLE.

VERSION 1.1

Assembly Instructions



Elise


Outdoor Sofa

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


If you're having difficulty, our friendly Customer Care team is always here to help. Call us at 1.888.746.3455 during business hours, email service@article.com or chat live at article.com.



TIME



2 PEOPLE



DIFFICULTY

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	Sofa	1
B	Support leg	1
C	Seat cushion	1
D	Back cushion	2






Hardware may loosen over time, check the bolts regularly and tighten if necessary.

HARDWARE INVENTORY		
ID	DESCRIPTION	QTY
E	Bolt M6X35mm	2
F	Washer Ø18X2mm	2
I	Allen key M4x80mm	1

1


Insert support leg (B) align with holes on seat deck (A) and secure with bolts (E) and washer (F) by using allen key (I).



! Step 2: Once all bolts are placed, completely tighten all bolts.


2

Turn the product upright and adjust the levelers at the bottom of the legs (if needed) to balance the Sofa sectional.



3

Insert seat cushion (C) first, then insert back cushions (D) after.



4

Your Sofa is ready to be used.

