


ARTICLE.

VERSION 1.0

Assembly Instructions



LEIF


Armoire

ASSEMBLY INSTRUCTIONS


Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email service@article.com or chat live at [article.com](https://www.article.com).




TIME



DIFFICULTY



OF PEOPLE




REQUIRED TOOL
Pozidriv screwdriver



PARTS INVENTORY			
ID	DESCRIPTION		QTY
1	CABINET		1
2	TOP PANEL		1
3	LEFT PANEL		1
4	RIGHT PANEL		1
5	LEFT DOOR		1
6	RIGHT DOOR		1
7	LEFT BACK PANEL		1
8	RIGHT BACK PANEL		1
9	HANGING BAR		1

PARTS INVENTORY CONT.			
ID	DESCRIPTION		QTY
A	ALLEN KEY		1
B	M6 x 40MM BOLT		33
C	M6 LOCK WASHER		33
D	M6 WASHER		33



! Structural integrity is warranted only if all fasteners are properly installed & tightened, and the bed is moved only per instructions.





1





2






3





4



5



6




! Adjust the levelers to stabilize the furniture if it is unbalanced.


DOOR ADJUSTMENT INSTRUCTIONS



During shipping, the doors of your cabinet may have shifted slightly. This can easily be corrected by tightening a few screws. Always start by adjusting the top hinge on the affected door.




REQUIRED TOOL



Ensure all levelers adjusted and furniture is balanced.


1A

If the door is crooked, adjust hinge(s) up or down:




1B

If the door needs adjustment side to side:



1C

If the door needs adjustment forward or backward:






ANTI-TIP RESTRAINT INSTALLATION

WARNING!

Children have died from furniture tipover.
To reduce the risk of furniture tipover:


- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lower drawers.




TIME




OF PEOPLE



DIFFICULTY



REQUIRED TOOL
8MM / 5/16" DRILL BIT




REQUIRED TOOL

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	BRACKET 	4
B	M4 × 20MM SCREW 	4
C	M8 × 51MM PLUG 	4
D	M6 × 70MM SCREW 	4
E	STRAP 	2




Hardware (C/D) to attach brackets to wall is designed for drywall. To attach this unit to another type of wall, consult with your local hardware store.

1






Attach pair of brackets to top corners of the back of the unit.

2



Mark on wall where second pair of brackets should be placed.


3




Drill holes in wall using 8mm / 5/16" drill bit.

4A

Align brackets on unit with brackets on wall.



4B




Pull strap down until it snap-locks.

SOFT CLOSING DRAWERS

ADJUSTMENT INSTRUCTIONS


If you're having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email service@article.com or chat live at [article.com](https://www.article.com).

FIXED A CROOKED DRAWER




⚠ Adjust levelers on either side of drawer as needed to straighten drawer.


1 REMOVE DRAWER



2



1 — INSTALL DRAWER



2

