


ARTICLE.

VERSION 1.0

Assembly Instructions



ELLORY

72" - 92" Extendable Dining Table

ASSEMBLY INSTRUCTIONS

Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.


If you’re having difficulty, our friendly Customer Care team is always here to help. Call us at 1.888.746.3455 during business hours, email service@article.com or chat live at article.com





TIME



OF PEOPLE




DIFFICULTY

PARTS INVENTORY		
ID	DESCRIPTION	QTY
A	TABLE TOP 	1
B	LEGS 	4

PARTS INVENTORY CONT.		
ID	DESCRIPTION	QTY
C	ALLEN KEY 	1
D	M8 x 80MM BOLT 	8
E	M8 LOCK WASHER 	8
F	M8 FLAT WASHER 	8

1


⚠ Ensure the furniture is set on a clean, soft surface to prevent any damage or fold corners on carton to be able to assemble legs.




2




⚠ Tighten all bolts 100%



3



4



! Adjust the levellers of the furniture when it's unbalanced