


ARTICLE.

VERSION 1.0

Assembly Instructions



LAHOLM


Sofa

ASSEMBLY INSTRUCTIONS


Read these instructions carefully and keep for future reference. Refer to parts inventory for guidance, and ensure you have all pieces before starting.

When assembling, place all parts on a soft, clean, and flat surface such as a carpet to prevent scratches.

If you’re having difficulty, our friendly Customer Care team is always here to help. Call us at **1.888.746.3455** during business hours, email **service@article.com** or chat live at **article.com**.











TIME









DIFFICULTY




OF PEOPLE

PARTS INVENTORY			
ID	DESCRIPTION		QTY
A	BASE		1
B	BACK FRAME		1
C	RIGHT ARM		1
D	LEFT ARM		1
E	CENTER LEG		2
F	SEAT CUSHION		3
G	BACK CUSHION		3
H	SIDE CUSHION		3



TOOLS INVENTORY			
ID	DESCRIPTION		QTY
I	ALLEN KEY		1
K1	M6 x 70MM BOLT		1

HARDWARE INVENTORY			
ID	DESCRIPTION		QTY
J	M6 x 40MM BOLT		6
K2	M6 x 70MM BOLT		2
L	M6 x 90MM BOLT		8
M	NUT		4

1



! Do not completely tighten bolts.





! Note use bolt (K1) only as a tool to insert temporarily and hold nut (M) to holes underneath the seat, while connecting nut (M) to bolt (L).





Remove bolt (K1) after nut (M) is completely attached to bolt (L).

2


Insert bolt (K2) in holes to attach legs (C) and (D) to backseat (B) to complete sofa assembly.





! Do not completely tighten bolts.



3




! Do not completely tighten bolts.



! Once all bolts are placed, completely tighten



4



5

